

NORTH AIRTRACK

INFLATION

1. Place your rolled-out air track on the floor free of obstructions or sharp objects
2. Open valve on mat and make sure the valve center piece is popped-up (inflation position)
If the center piece is locked down, please use your finger to turn it in clockwise direction till its popped up.
3. Connect the hose tip with the valve by a simple twist.
4. Pump until it is fully inflated. Please do not over-inflate.

NOTES:

In case that the valve is loose, please use the tool in the orange tube to turn it tight before inflating the air track. In rare cases the air track cannot be inflated 100%, please stop pumping. Take off the hose from valve and check if air is leaking from the valve. If it does, the valve needs to be replaced. If no leaking is found, air pump needs to be replaced.

DEFLATION

To deflate, open the valve cap. Air track will deflate itself.
Close the valve with the security cap and store the air track in the carry bag.

INFLATION INSTRUCTIONS

1.



2.



3.



4.



WARNING:

- Adult supervision is required.
- This is not a lifesaving device.
- Do not leave children unattended in or around water.
- Do not use this air track as a boat.
- Do not inflate with an air compressor.
- Keep away from fire.
- This product is delivered with a carry bag. Keep it away from children. Suffocation hazard.